



PC-EFTPOS Software Upgrade For ANZ Customers

Version 1.00
Sept 2011

Revision Record

Version	Date	Author	Document Preparation	Revisions
1.00	Sept '11	Richard Bolt	Richard Bolt	Document Creation

Copyright ©PC-EFTPOS Pty Ltd, 2010. This document contains information proprietary to PC-EFTPOS Pty Ltd. Any reproduction, disclosure or unauthorised use of this material is expressly prohibited except as may be authorised by PC-EFTPOS Pty Ltd in writing.

1/9a Ponderosa Parade
Warriewood NSW 2102
Australia
Phone +61 2 9998 9800
Fax +61 2 9986 0530
www.pceftpos.com


1. PC-EFTPOS Software Upgrade

- 1) Download the following file from the PC-EFTPOS website


http://www.pceftpos.com.au/files/released/CurrentReleaseCD/Software/Installer/NoConfig_PC-EFTPOSSetup.exe

- 2) This file is used to upgrade both your server PC and register PCs


- 3) Run the file on the server PC first




- 4) Select all the default settings and click Next on each screen




- 5) Click Install and let the software install
This may take a few minutes



- 6) Click on Finish



- 7) Repeat steps 3 to 6 on each of your register PCs
- 8) Once the server and all registers have been installed, your software upgrade is complete
To confirm the upgrade was successful, perform a logon from each of the registers
- 9) Open the PC-EFTPOS Client by using <Func> 11114440 <Enter> on the EFTPOS terminal
Then Click on “Ctrl Panel” then “Logon”



- 10) Terminal should log on successfully and say “READY”